


Optional Manual Bleed Valve

This is only for the purpose of manually venting the body cavity and DBB testing.

This assembly does not alter the bidirectionality of the valve.

It must only be used for gaseous services.

When not being used for bleeding, the valve should be closed and the outlet should be plugged.



Sealing of valve seats with manual bleed valve

